






MAIN MENU



IP address: 192.168.125.1



NOTE: minimumAllog can be in STOP mode

General notification




UI Status message






Battery level



Test GPRS/GSM modem - Signal level



ERROR CODE






miniOMNIAlog Switch On



Remove plastic tab

miniOMNIAlog keyboard



-  S – Select = Select item
-  E – Enter = Confirm item

Rev.2 -
03.11.2014 -

Reminder

From FW 0.12.22

miniOMNIAlog

Via F. Serpero, 4/r2
20060 MASATE (MI)
ITALY

indusTries
NEXT

indusTries
NEXT